

EP-ATK

Automatic Transmissions kit

Instructions

This kit is selectively designed to clean and regenerate automatic transmissions and power steering systems that use ATF only.

The kit should be performed as part of the normal service when gearbox oil is changed.

Step #1 Automatic Transmission Cleaner (EP-ATK_001)

1. Can only be used with the Eco-Power automatic transmission service machine
2. Perform according to service machine instructions

Step #2 Automatic Transmission Treatment (EP-ATK_002)

1. Add EP-ATK-002 to the automatic transmission fluid
2. Do not overfill.
3. 325 ml treats up to 6.5 litres of automatic transmission fluid.
4. For power steering systems use 50 ml of EP-ATK-002 to each litre oil

Disclaimer

The data concerning properties and applications of the indicated products are offered in good faith and are based on our research and practical experiences. Due to the versatility of the application possibilities, it is impossible to mention all details and we do not assume any obligations or responsibilities resulting from this.